

# Correct installation of the polymeric stay wire insulator kit

Polymeric stay wire insulator kit is delivered as a complete assembly for the easiness of installation and handling. The kit includes all necessary accessories.



1

Open the kit and remove the securing tapes from the reel. Make sure to avoid the insulator from hitting the ground.




2

Attach the top end of the wire on the pole with a bolt. Make sure to avoid the insulator from hitting the pole.



3

Attach the come-a-long clamp on the wire and tension it to the desired tightness with a hoist. Install the stay wire clamp on to the eye-link.



4

Guide the wire through the clamp and finish the installation as instructed in installation instruction.



5

Remove the load from the hoist on to the wire and remove the hoist and the come-a-long clamp. Tighten the stay wire with adjustment nuts to desired value.



6

Add the stay wire markers.



7

Make sure that the installation is complete and safe.

## Extremely strong polymeric stay wire insulator SDI69

- Withstands voltage loads very well, highest system voltage 24 kV
- Strong structure, but lightweight
- Strength, SMFL up to 130 kN
- Shockproof
- Weatherproof
- UV resistant



# ENSTO

ensto.com

